


WHAT'S IN THE BOX

Your Bungalow® Liner Includes: (1) Bungalow® Liner, (1) Carry Bag

SET UP

NOTE: This accessory is intended to be installed under the primary fabric top of your E-Z UP® cabana.

1. Set up your E-Z UP® cabana in the area that you intend to shade according to the owner's manual instructions. Open the frame to approximately 3/4 of its fully-opened size and **do not** extend legs.
2. Remove fabric top from frame. Remove Bungalow® Liner from storage bag.
3. With the Bungalow® Liner in hand, step inside to the center of your cabana's frame.
4. Slightly pull down the **Peak Pole** in order to easily reach the top of the **Peak Pole**. (**Fig. A**)
Drape the Bungalow® Liner over the **Peak Pole** and line up center peak of the Bungalow® Liner with top of **Peak Pole**. (**Fig. B**)
5. Locate the two **FXT Clips** found on each corner of the Bungalow® Liner and attach them to the **Corner FXT Attachment Points** on the frame of the cabana. (**Fig. C**)
6. Repeat **Step 5** for all corners.
7. Before continuing, check to make sure the Bungalow® Liner is in line with the center of the **Peak Pole**.
8. Step outside the frame of the cabana, and place fabric top over the semi-opened frame. Pull the fabric top down over the frame corners, pushing the **Hook and Loop Strips** firmly together. (**Fig. D**)
9. Locate one of the **Top Attachment Points**. Remove the **Top Attachment Nut**. Place the Bungalow® Liner's **Paracord Loop** on the **Top Attachment Point**.* (**Fig. E**)
10. Line up the **Grommet Holes** on the sides of the fabric top to the frame **Top Attachment Point**. Replace **Top Attachment Nut** and tighten until snug. **Do not** over tighten. (**Fig. F**)
11. Repeat **Step 9** and **Step 10** for all **Top Attachment Points**.*
12. Finally, fully set up the cabana according to the owner's manual instructions.



BUNGALOW®

ACCESSORIES INSTALLATION



TAKE DOWN

Once Bungalow® Liner is installed, it may remain on cabana when stored. Refer to owners manual for take-down instructions for cabana.

RECOMMENDATION

If Bungalow® Liner is stored while installed in cabana, check Paracord Loops and FXT Clips to ensure they have remained in correct positions.

CARE and MAINTENANCE

- Use a mild soap (not detergent) and plenty of water for cleaning. Let the E-Z UP® Bungalow® Liner dry completely before closing or storing to avoid mildew.
- Store in the Carry Bag provided.

BUNGALOW® CURTAIN INSTALLATION







WHAT'S IN THE BOX

Your Bungalow® Curtain Includes: Bungalow® Curtain(s), (1) Carry Bag, Tie Back(s)

SET UP

NOTE: Completely set up your Bungalow® cabana in the area that you intend to shade according to the owner's manual instructions. Do not, however, pull the fabric corners down.





1. With the shelter's top fabric folded up and out of the way, and standing outside of the cabana, hook the curtain's **FXT Clips** on the corner **FXT Attachment Points**. (Fig. A)
2. From inside the cabana, attach **Hook and Loop Strips** around the cabana's legs. (Fig. B)
3. Pull the fabric corner down over the leg and match the **Hook and Loop Strips** to those on the frame for secure fit. (Fig. C)
4. On both sides of the curtain hook the side **FXT Clips** onto the middle truss **FXT Attachment Point**. (Fig. D)
5. On both sides attach **Hook and Loop Strips** around the trusses. (Fig. E)
6. Repeat steps for each curtain.



BUNGALOW® CURTAIN INSTALLATION

TIE BACKS

1. Remove **FXT Clips** from the **Truss Attachment Points** and attach them on the **Corner FXT Attachment Points**. (Fig. F)
2. Zip the curtain together at the leg. (Fig. G)
3. From outside the cabana, insert **Tie Back** through the **Belt Loop**, pull back curtains toward the leg and fasten **Tie Back Hook and Loop Strips** to secure. (Fig. H)



IMPORTANT INFORMATION

- Always stake or weight down your Bungalow® cabana. Do not use in any potentially windy or rainy weather. Wind, rain and snow can damage the Bungalow® cabana and may also result in injury to you or others. Therefore, do not rely on the cabana for protection in heavy or prolonged weather storms. Do not leave your Bungalow® cabana unattended.
- Do not use the cabana in a lightning storm.
- The Bungalow® cabana is designed as a seasonal shelter.
- Ensure that all curtains zip together at the same time before installing anchoring devices.
- Keep all flame and heat sources away from the fabric top. Do not build fires within the cabana enclosure.

FABRIC CARE

The Bungalow® fabric curtains feature a soil- and stain-resistant finish that makes clean up a breeze. Spot wash by sponging briskly with soapy solution of solvent-free natural soap in lukewarm water. Rinse thoroughly with clean water to remove soap and air dry. For stubborn stains, use a fabric spot remover. Follow directions on the container. Rinse thoroughly with clean water and air dry completely before storing.