





INSTRUCTIONS FOR **WEIGHT BAG** **ACCESSORIES**


Note: If using curtain walls, ensure that all walls zip together at the same time before installing weight bags or other anchoring devices.

Completely set up your Bungalow® Pavilion in the area that you intend to shade according to the owner's manual instructions.

Step 1. Fill weight bags with sand as full as possible for maximum efficiency. Each weight bag is designed to hold 50 lbs. of sand. (1a) Lay bag down next to the leg and insert the quick release pin through the grommet on the strap. Continue on through hole in the leg of the Bungalow® Pavilion. (1b) Swing the wire catch around to snap onto the end of the pin protruding from the leg.



Step 2. Stand the weight bag up and wrap the quick attachment strap around the leg and secure against the loop end of the strap on the weight bag by pressing firmly.



- Attach the weight bag to each leg.



Fabric Care:

- The weight bag fabric can be cleaned with mild soap (not detergent) and water once the sand is removed. Let the fabric dry completely before storing.

Important Information:

- Always stake or weight down your Bungalow® Pavilion. Do not use in any potentially windy or rainy weather. Wind, rain and snow can damage the Bungalow® Pavilion and may also result in injury to you or others. Therefore, do not rely on shelter for protection in heavy or prolonged weather storms. Do not leave your Bungalow® Pavilion unattended.
- Do not use shelter in a lightning storm.
- The Bungalow® Pavilion is designed as a seasonal shelter.
- Keep all flame and heat sources away from the fabric top. Do not build fires within the shelter enclosure.

For online warranty service, parts and accessories, contact: **bungalowbyezup.com**

International E-Z UP, Inc.

1900 Second Street, Norco, California 92860 USA

888.474.3583