



WHAT'S IN THE BOX

Your Camping Cube™ Includes: Camping Cube, Accessory Bag, Stakes, and Door Mat

SET UP

NOTE: To prolong the life of the Camping Cube floor, select a leveled site clear of rocks, branches, and other hard or sharp objects.

- 1. Set up your E-Z UP® Shelter in the area that you intend to camp, leaving your Shelter legs retracted.
- 2. Slightly lift up the fabric valance corners on the corner of the shelter. Repeat on remaining corners.
- **3.** Remove the Camping Cube from the carry bag and center the Camping Cube under your shelter.
- **4.** Spread out the Camping Cube, floor side down and position the doorway at your desired entrance.

NOTE: Step 5 will be different dependent on shelter*

5. Attach the **Ceiling Truss Clips** (see Product Key) to the shelter.

Open Truss Shelters

- 1) Locate the **Center Ceiling Truss Clips** (with long orange webbing). (Fig. A) Attach Center Ceiling Truss Clips to peak of the shelter, adjacent to each other.
- 2) Attach the additional four **Ceiling Truss Clips** to the roof truss system.

Cross Truss Shelters

snap back and hit you.

- 1) Locate the center **Center Ceiling Truss Clips** (with short orange webbing). (Fig. A2) Attach Center Ceiling Truss Clips to peak of the shelter, adjacent to each other.
- *Illustrations of truss systems may vary slightly dependent on shelter.
- **6.** Locate the **Corner Truss Clips** (which include elastic cords). Attach the **Corner Truss Clips** to the outer truss on adjacent sides. (Fig. B) Caution: Attach carefully as the Corner Truss Clips include elastic cords that may
- 7. Attach the Side Truss Clips located on each of the four sides of the Camping Cube to your Shelter's truss system. (Fig. C)
- **8.** Pull the fabric top corner down over the frame leg. Repeat on remaining corners.
- **9.** Raise your shelter to its full height.
- 10. Connect the S Hooks into the provided hole on the lower part of each leg. (Fig. D)
- 11. Wrap the Hook and Loop Straps around the legs of the shelter. (Fig. E)
- 12. Locate the Fabric Attachment Tabs located at the bottom of each wall of the Camping Cube. Insert a spike through the Fabric Attachment Tab grommet. Drive the spike firmly into the ground. (Fig. F)
- 13. Secure the Door Mat to the Camping Cube by attaching each Door Mat Hook into the **O Rings** located at the bottom of the door. (Fig. G) Insert a spike through each of the Door Mat grommets to secure.

TAKE DOWN

1. Repeat steps in reverse of assembly.

CARE & MAINTENANCE

- Use a mild soap (not deteraent) and plenty of water for cleaning. Let the E-Z UP® Camping Cube[™] dry completely before closing or storing to avoid mildew.
- Store in the Carry Bag Provided.

Important Information:

- Interior O Ring Hanger(s) is not to exceed 5lb. hanging weight.
- E-Z UP® Instant Shelter products are designed as a temporary shelter.
- Do not leave up for extended periods.
- Do not use your Camping Cube in a lightning storm.
- Do not leave your Camping Cube product unattended.
- Do not build fires within your Camping Cube enclosure

Warranty Information: www.ezup.com/warranties

WARNING!

•


Always weigh down your E-Z UP® shelter. Do not leave your E-Z UP® shelter unattended. Do not depend on Weight Bags to secure shelter in heavy winds. For your safety, stake your E-Z UP® shelter down in any potentially windy or rainy weather.

INSTRUCTIONS FOR



PRODUCT KEY

- A Corner Truss Clips (with elastic cords)
- **B** Side Truss Clips
- Center Ceiling Truss Clips
- Hook and Loop Straps
- S Hooks
- 🚹 Door Mat
- **G** Door Mat Hooks
- O Rings
- Fabric Attachment Tabs
- Ceiling Truss Clips (Open Truss frames only)



OPEN TRUSS ONLY




Fig. A Open Truss




Fig. A2 Cross Truss





Fig. B









Fig. D









The #1 Instant Shelter® Brand in the World

ezup.com



800-45-SHADE





