# Instructions for Sidewall/Corner Curtain Accessories

**Completely set up your Bungalow® Pavilion in the area that you intend to shade according to the owner's manual instructions. Do not, however, pull the fabric corners down.**

**Step 1.** With the fabric corners still folded back, hang the sidewalls or corner curtains on the outer side of the trusses. The sidewalls or corner curtains will hang between the fabric valance and the other truss.



**Step 2.** (2a) Align the bottom of the fabric wall "V" with the frame leg to ensure the walls are centered. (2b) Slip the hook over the stainless steel cables.



(2b)

(2a)

**Step 3.** Pull the fabric corner down over the leg and match the quick attachment strips to the frame for a secure fit.

**Step 4.** From the inside of the Bungalow® Pavilion, wrap the quick attachment straps around the leg and secure. These can be found just below the slider, at the midpoint of the screen wall and at the bottom of the screen wall.



**Special Note:** For double layered walls, the quick attachment strap may have slipped inside a layer. Just reposition the straps by pulling back through the indexed slits.

**Key Tip:** If also installing an insect screen, the full sidewall or corner curtains should be placed outside of the screen.



Continued

© Copyright 2013 International E-Z UP, Inc. USA. All rights reserved. IN.BNG.SWCC.0423

# Instructions for Sidewall/Corner Curtain Accessories

**Step 5.**

**For Sidewalls:** Insert the sidewall tie back through the belt loop on the outside of the curtain wall. Pull each side toward the leg and wrap the tie back around the fabric to secure. If walls are to be closed, ensure that all walls zip together at the same time before installing anchoring devices.

**For Corner Curtains:** Insert the tie back through the belt loop on the outside of the curtain. Pull each side toward the leg and wrap the tie back around the fabric to secure.



**Step 6.** Repeat the above steps for all legs.

**Fabric Care:**

• The Bungalow® Sunbrella® fabric curtain walls feature a soil- and stain-resistant finish that makes clean-up a breeze. Spot wash by sponging briskly with soapy solution of natural soap in lukewarm water. Rinse thoroughly with clean water to remove soap and air dry. For stubborn stains, use a fabric spot remover. Follow directions on the container. Rinse thoroughly with clean water and air dry completely before storing.

**Important Information:**

• Always stake or weight down your Bungalow® Pavilion. Do not use in any potentially windy or rainy weather. Wind, rain and snow can damage the Bungalow® Pavilion and may also result in injury to you or others. Therefore, do not rely on the pavilion for protection in heavy or prolonged weather storms. Do not leave your Bungalow® Pavilion unattended.

• Do not use the pavilion in a lightning storm.

• The Bungalow® Pavilion is designed as a seasonal shelter.

• Ensure that all sidewalls zip together at the same time before installing anchoring devices.

• Keep all flame and heat sources away from the fabric top. Do not build fires within the pavilion enclosure.

For online warranty service, parts and accessories, contact: **bungalowbyezup.com**
International E-Z UP, Inc.
1900 Second Street, Norco, California 92860 USA
**888.474.3583**

© Copyright 2013 International E-Z UP, Inc. USA. All rights reserved. IN.BNG.SWCC.0423